

cleaning guide



Don't stress when someone makes a mess.

The STAY™ collection is designed for carefree outdoor living. With the right care and a few simple cleaning steps, your STAY products will stay fresh, comfortable and looking their best season after season.

Whether it is spilled drinks, sunscreen stains or everyday outdoor dirt, most marks can easily be removed.

With STAY™, relaxing always comes first.



Scan to view the STAY 'how to clean' videos.

Sunproof® fabrics



For common stains



Brush off loose dirt, then vacuum clean.



Pre-clean with a neutral universal agent.



Stain removal agents should only be worked in with a clean, damp and absorbent cloth.



After each cleaning remove any residual cleaning agent, using spray extraction.

| Spilled substance | Recommended cleaning solutions |
|--|---|
| Blood, animal excreta, baby food, chocolate, milk, egg, ice cream, vomit | Fresh stains: treat with an alkaline cleaning agent, rinse off immediately. Dried-in marks: treat with an enzyme agent, note reaction time, wipe off gently. |
| Cola, lemonade, honey, street dirt | Treat with a normal commercial oxidative bleaching agent. |
| Candle wax, chewing gum, face powder, fat, floor polish, glue, nail varnish, oil paint, | Treat with an agent containing solvent, using manual method as well (scrape off, beat lightly, vacuum clean when completely dry). |
| Ink, coloured pencil, chalk, flower stains, furniture polish, ketchup | Treat with dye-fixing agent, possibly treat afterward with an oxygen bleaching agent. |
| Beer, brandy, coffee, fruit juice, fruit stains, grass stain, jam, wine, mould stain, perfume, tea | Fresh stains: treat with weak solution of organic acid (slightly acidic cleaning agent), rinse off immediately. Dried-in marks: treat with a normal oxidative bleaching agent. |

cleaning guide

Teak wood



For easy maintenance



Brush off loose dirt with a stiff brush, follow the natural grain of the timber to avoid scratching the wood.



Use clean water and a cloth to lightly moisten the wood.



Wash down the surface, using a soft cloth and a teak cleaner or a homemade solution of vinegar and warm water (250ml vinegar to 4l of water).



Allow the vinegar solution to penetrate into the teak for 15 minutes.



Clean the timber with a sponge, following the grain of the wood.



Rinse lightly from the bottom up with a hose.



Allow the wood to air dry.

For common stains

- Clean the wood as above.
- If the stain isn't lifting, try adding a dash of bleach to the cleaning fluid.
- For stubborn stains, you can lightly sand the affected area with a fine sandpaper.